

ATM REMOVABLE PREFORMED POLYMER TAPES APPLICATION INSTRUCTIONS

- Air temperature MUST be 40°F (5°C) and rising.
- ATM Removable Primer is to be used under the following marginal conditions:
 - 1) When air or surface temperatures are expected to fall below 40°F (5°C) after installation.
 - 2) Rain is expected within 24 hours after installation.
 - 3) When road surfaces are marginal.
- Surface must be completely dry and confirmed by a moisture bag test.
- Surface must be free of any contaminants such as oils, grease, sand, dirt, dust, loose aggregate, curing compound mud, soil and salt.
- Portland Cement concrete curing compound must be completely removed by brushing, grinding, or sandblasting the road surface.
- Do not apply tape directly on seams, joints, deteriorating markings or substrates.
- Do not overlap tape, always use butt joints.
- Firmly tamp tape in the same direction as tape was applied using an approved tamper cart with a minimum of 200 lb. (90 kg) load. Never twist the tamper cart during tamping. Repeat tamping as necessary to insure tape has completely conformed to road surface.
- When removing tape, pull tape at a 90° angle to the pavement.
- Marked roadway can be open to traffic immediately.